

### Resetting

After testing, reset the call point by interlocking the reset key with reset mechanism which is located on the front face. Turn the reset key clockwise until the yellow and black striped indicator is no longer visible.

### Earth Continuity Plate

An earthing plate (Fig. 4) is provided to maintain earth continuity of metal conduits or cable glands. This must be placed behind the backbox prior to fixing the box to the wall.

### Important Information

The use of lubricants, cleaning solvents or petroleum based products should be avoided. The O-ring, part no 31523-007 should be replaced when refitting or replacing the waterproof cover.


### Transparent Hinged Cover

To provide additional protection against accidental operation, a Transparent Hinged Cover, part no 44251-189, is available or 44251-175 for multiples of 10. This can be fitted to the manual call point included with this guide.

### Dust Cover

To ensure optimal performance, leave the dust cover on the product and remove on commissioning.

For further information, please refer to PP2457 which is available on request. For further information on the XP95 IS System, please refer to the XP95 IS Engineering Product Guide PP1095.



© Apollo Fire Detectors Limited 2007/TP/SP

© Apollo Fire Detectors Limited 2014

Apollo Fire Detectors Limited, 36 Brookside Road, Havant, Hampshire, PO9 1JR, UK  
Tel: +44 (0) 23 9249 2412 Fax: +44 (0) 23 9249 2754  
Email: techsales@apollo-fire.co.uk Website: www.apollo-fire.co.uk



## XP95® IS Manual Call Point Installation Guide

### General

This guide describes the installation of the following products:

Part Number	Product Name	Type	Colour
55200-940	XP95 IS Manual Call Point	Outdoor	Red
55200-942	XP95 IS Manual Switch	Outdoor	Yellow
55200-944	XP95 IS Manual Switch	Outdoor	Blue

### Installation

- Place the earthing plate behind the backbox, if required (see Earth continuity plate section). Fit the backbox to a flat surface using the four fixing holes. The cable entry holes should be in the vertical plane. The backbox can be mounted with either the single or double entry holes at the top Fig. 1).

*Note: Cable entry from the bottom of the call point is recommended if there is a possibility of moisture condensing within the conduit or cables.*

- Run the cables into the backbox and connect them to the terminal block as shown in Fig. 3. Ensure that the functional earth/screen is maintained and all terminations are in accordance with BS EN 60079-14.
- Set the unit address on the DIL switch in accordance with the address table overleaf.
- Ensure that the O-ring is correctly seated in the Manual Call Point moulding. Place the cover squarely over the backbox and tighten the 6 fixing screws with the 2.5mm hexagonal key (supplied) to lock the cover. **Do not use excessive force, do not over tighten screws.**

The XP95 IS Manual Call Point is a 'type A' call point and is suitable for outdoor use.

### Wiring Details

To maintain the integrity of the 'type A' product it is essential that suitable cable glands be used.

A suitable thread sealant is recommended to maintain IP rating.

### Technical information

Operating Voltage	14-22V DC
Quiescent Current	230µA
Alarm Current (LED On)	1.23mA
Operating Temperature	-20°C to +60°C (T4) -20°C to +40°C (T5)

### LED Indicator

- ⊙ Illuminated red (under CIE control) when call point is operated

## Commissioning

Manual Call Points must be installed to comply with the requirements of the ATEX directive or another applicable codes of regulations. All unused cable entry ports must be sealed using suitable stopping plugs to give the required level of ingress protection.

Ensure that the call point is fully assembled before testing. A XP95 Test Set, part no. 55000-870, may be used to carry out functional testing of individual units (from the safe area only). The test set can also perform data integrity tests of an entire system.




Fig. 1 Backbox




Fig. 3 Terminal Block Connections




Fig. 5 Sample Address Setting




Fig. 2 Front Cover




Fig. 4 Earthing Plate

Terminal Block	PCB Legend	Flying Lead Colour
TB2	Y	Red
TB2	R	Black
TB2	BL	Blue
TB3	R	Green
TB3	BL	Pink

Fig. 6 Flying Lead Wiring Diagram

## Address Setting

The address of the Manual Call Point is set using the DIP switch. All segments of the switch are set to 0 or 1, using a small screwdriver or similar tool.

A complete list of address settings is shown in the following table.

addr	DIL switch setting 1234567	addr	DIL switch setting 1234567	addr	DIL switch setting 1234567	addr	DIL switch setting 1234567	addr	DIL switch setting 1234567
1	1000000	11	1101000	21	1010100	31	1111100	41	1001010
2	0100000	12	0011000	22	0110100	32	0000010	42	0101010
3	1100000	13	1011000	23	1110100	33	1000010	43	1101010
4	0010000	14	0111000	24	0001100	34	0100010	44	0011010
5	1010000	15	1111000	25	1001100	35	1000010	45	1011010
6	0110000	16	0000100	26	0101100	36	0010010	46	0111010
7	1110000	17	1000100	27	1101100	37	1010010	47	1111010
8	0001000	18	0100100	28	0011100	38	0110010	48	0000110
9	1001000	19	1100100	29	1011100	39	1110010	49	1000110
10	0101000	20	0010100	30	0111100	40	0001010	50	0100110
51	1100110	61	1011110	71	1110001	81	1000101	91	1101101
52	0010110	62	0111110	72	0001001	82	0100101	92	0011101
53	1010110	63	1111110	73	1001001	83	1100101	93	1011101
54	0110110	64	0000001	74	0101001	84	0010101	94	0111101
55	1110110	65	1000001	75	1101001	85	1010101	95	1111101
56	0001110	66	0100001	76	0011001	86	0110101	96	0000011
57	1001110	67	1100001	77	1011001	87	1110101	97	1000011
58	0101110	68	0010001	78	0111001	88	0001101	98	0100011
59	1101110	69	1010001	79	1111001	89	1001101	99	1100011
60	0011110	70	0110001	80	0000101	90	0101101	100	0010011
101	1010011	106	0101011	111	1111011	116	0010111	121	1001111
102	0110011	107	1101011	112	0000111	117	1010111	122	0101111
103	1110011	108	0011011	113	1000111	118	0110111	123	1101111
104	0001011	109	1011011	114	0100111	119	1110111	124	0011111
105	1001011	110	0111011	115	1100111	120	0001111	125	1011111
								126	0111111

The switch in Fig 5 shows address setting 78 as an example of how to set the address

## Troubleshooting

Before investigating individual units for faults, it is important to check that the system wiring is fault free. Earth faults on data loops or interface zone wiring may cause communication errors.

Many fault conditions are the result of simple wiring errors. Check all connections to the unit. **Do not overtighten screws** when mounting the backbox.

## Fault Finding

Problem	Possible Cause
No response or missing	Incorrect address setting Incorrect loop wiring
Alarm condition	Element incorrectly fitted or broken

## Routine Testing

Push the centre of the Element (printed with two black arrows and a circle) until the yellow and black striped indicator is visible. Observe routine test requirements as specified in the applicable local codes.